

SPADEADAM MISSION NUMBER 1132 24 Oct 2007
START 1119:31 CALLSIGN SQUAWK AIRCRAFT
END 1153:59 MRH 15 2630 TOR
BASE MR

PMR6

MOD/0/29A

REPORT 13 sqn Marham
SCENARIO A202, R208, R206, P208, P100(SSS)
TARGET
THERE IS NO SIGNIFICANCE IN THE TIME TAKEN FOR AN A/C
TO BE ACQUIRED AFTER THE ENGAGE COMMAND HAS BEEN GIVEN.

FOR COMMCEN USE - TOR: TOT:

EDITED BY: DC@1207Z

MISSION REPORT

AIRCRAFT 2630

TIME THREAT SITE ACTION

1119:45 SSR 147.18/018.64/16279/159
1119:47 SSR 145.79/018.44/16279/159
1119:54 SSR 147.18/017.60/16279/159
1120:00 SSR 150.41/016.89/16279/159
1120:07 SSR 151.92/016.05/16279/159
1120:16 SSR 152.11/015.03/16279/159
1120:22 SSR 154.43/014.21/16279/159
1120:25 RC START RUN 1
1120:26 A202 BH1 ENGAGE
1120:30 SSR 155.22/013.19/16279/159
1120:37 SSR 154.68/012.21/16279/159
1120:40 R206 PL ENGAGE
1120:45 SSR 154.68/011.22/16279/159
1120:47 A202-2 BH1 MANUAL TRACK 075.16/015.62/45036
1120:50 A202-2 BH1 AUTO-TRACK 075.16/015.62/45036
1120:52 SSR 157.37/010.13/16279/159
1120:59 SSR 156.21/009.18/16177/158
1121:04 A202 BH1 ECM 075.16/015.62/45036
1121:07 SSR 159.39/008.51/16279/159
1121:09 A202 BH1 SCORE B
1121:14 SSR 165.26/008.43/14977/146
1121:18 SSR 167.47/008.49/00000/000
1121:22 SSR 167.29/008.48/00000/000
1121:24 A202-2 BH1 MANUAL TRACK 075.16/015.62/45036
1121:24 A202-2 BH1 AUTO-TRACK 075.16/015.62/45036
1121:29 SSR 173.61/008.40/00000/000
1121:37 SSR 179.35/008.36/12477/121
1121:44 SSR 184.18/008.45/11778/114
1121:50 A202 BH1 ECM 075.16/015.62/45036
1121:50 R206-1 PL ACQUIRED 167.37/008.05/11302
1121:51 SSR 187.91/008.51/07778/074
1121:55 A202 BH1 SCORE B
1121:59 SSR 193.92/008.69/06679/063
1122:06 SSR 197.97/009.16/00000/000
1122:10 A202 BH1 DISENGAGE
1122:10 R206 PL DISENGAGE
1122:14 SSR 201.48/009.88/09776/094
1122:21 SSR 197.53/010.34/10177/098
1122:28 SSR 197.05/010.83/10278/099
1122:30 RC END RUN 1
1122:33 RC START RUN 2
1122:35 SSR 194.71/011.24/10377/100
1122:42 SSR 192.33/011.67/10679/103
1122:50 SSR 190.12/012.11/10879/105
1122:55 SSR 191.20/012.56/11079/107
1123:02 SSR 188.64/013.04/11279/109
1123:10 SSR 187.19/013.58/11578/112
1123:17 SSR 184.21/014.11/11778/114
1123:18 SSR 182.61/014.14/11778/114
1123:26 SSR 181.05/014.72/11978/116
1123:32 SSR 181.32/015.27/12276/119
1123:39 SSR 179.58/015.74/12477/121
1123:47 SSR 177.18/016.09/12677/123
1123:54 SSR 174.76/016.28/12877/125
1124:01 SSR 172.43/016.32/13077/127
1124:09 SSR 169.34/016.25/13477/131
1124:16 SSR 165.29/016.26/00000/000
1124:23 SSR 162.82/015.92/15479/151
1124:31 SSR 160.51/015.57/16079/157
1124:35 A202 BH1 ENGAGE
1124:38 SSR 158.47/015.07/16079/157
1124:45 SSR 156.88/014.44/16177/158
1124:48 R206 PL ENGAGE
1124:52 SSR 155.89/013.72/16177/158
1124:55 A202-2 BH1 MANUAL TRACK 075.16/015.62/45036
1124:57 A202-2 BH1 AUTO-TRACK 075.16/015.62/45036
1125:00 SSR 155.69/012.94/16177/158
1125:07 SSR 155.05/012.17/16079/157
1125:14 SSR 152.44/011.75/15078/147
1125:17 A202 BH1 ECM 075.16/015.62/45036
1125:19 A202 BH1 SCORE B

1125:21 A202-2 BH1 MANUAL TRACK 075.16/015.62/45036

PMR6

MOD/0/29A

1125:21 SSR 149.73/011.63/00000/000
1125:27 SSR 148.96/011.25/10777/104
1125:34 SSR 144.06/011.03/12378/120
1125:36 SSR 141.80/010.97/12578/122
1125:38 R206 PL NOT FOUND
1125:39 A202 BH1 ECM 075.16/015.62/45036
1125:39 A202 BH1 DISENGAGE
1125:39 R206 PL DISENGAGE
1125:40 A202 BH1 SCORE B

1125:43 SSR 138.00/010.78/13979/136
1125:45 RC END RUN 2
1125:48 RC START RUN 3
1125:49 SSR 136.42/010.85/00000/000
1125:56 SSR 132.93/010.91/15078/147
1126:04 SSR 129.78/011.32/15377/150
1126:11 SSR 128.09/011.90/15577/152
1126:19 SSR 126.66/012.68/15679/153
1126:26 SSR 127.04/013.44/15679/153
1126:33 SSR 127.95/014.23/15777/154
1126:41 SSR 129.96/014.87/15879/155
1126:48 SSR 130.21/015.35/15977/156
1126:55 SSR 133.11/015.59/15977/156
1127:03 SSR 136.23/015.59/15977/156
1127:10 SSR 139.16/015.34/15977/156
1127:17 SSR 141.83/014.85/15977/156

1127:24 R206 PL ENGAGE
1127:25 SSR 143.86/014.20/15977/156
1127:32 SSR 145.17/013.41/15977/156
1127:39 SSR 147.16/012.71/15879/155

1127:42 R206-1 PL ACQUIRED 136.29/013.81/15853
1127:47 SSR 150.65/012.59/15278/149
1127:55 SSR 156.42/012.53/00000/000
1128:01 SSR 157.46/012.45/00000/000
1128:09 SSR 161.81/012.34/10777/104
1128:14 SSR 166.01/012.40/00000/000
1128:23 SSR 169.25/012.27/00000/000

1128:26 R208 BH5 ENGAGE
1128:29 SSR 174.88/012.19/07276/069
1128:36 SSR 178.31/012.10/04376/040
1128:38 SSR 177.04/011.99/03877/035
1128:51 SSR 183.74/010.73/01978/016

1128:52 R206 PL LOST CONTACT 167.95/010.33/01978
1128:53 SSR 181.99/010.56/01978/016
1128:55 R206 PL VISIBILITY 163.39/010.17/01978

1129:00 SSR 185.56/009.88/01876/015
1129:07 SSR 187.98/009.10/01876/015

1129:08 R208 BH5 NOT FOUND
1129:09 R208 BH5 DISENGAGE
1129:09 R206 PL DISENGAGE

1129:13 SSR 193.35/008.53/01778/014
1129:13 RC END RUN 3
1129:16 RC START RUN 4

1129:21 SSR 196.17/007.80/01778/014
1129:28 SSR 199.76/007.13/01778/014
1129:29 SSR 198.69/007.04/01778/014
1129:36 SSR 203.70/006.49/01778/014
1129:43 SSR 210.92/006.09/01778/014
1129:50 SSR 218.60/005.73/00000/000

1129:54 P100 R81 ENGAGE
1129:58 SSR 225.36/005.37/02076/017
1129:59 SSR 223.98/005.26/02076/017

1130:03 P100 R81 OPTICAL TRACK 211.25/003.46/02076
1130:06 SSR 231.90/004.96/02178/018
1130:13 SSR 238.48/004.42/02276/019
1130:20 SSR 246.84/003.96/02178/018
1130:21 SSR 245.96/003.87/02178/018
1130:28 SSR 254.17/003.26/02178/018

1130:30 P100 R81 LAUNCH 273.28/002.17/02178 SSS LAUNCHED
1130:35 SSR 264.88/002.75/02178/018
1130:42 SSR 279.28/002.29/02178/018
1130:50 SSR 301.49/001.69/02378/020
1130:53 SSR 316.78/001.51/02378/020

1131:01 SSR 347.66/001.49/02477/021
1131:08 SSR 016.11/001.82/02578/022
1131:16 SSR 036.40/002.36/02578/022
1131:23 SSR 054.38/002.55/02677/023
1131:30 SSR 072.12/002.32/02578/022
1131:34 SSR 078.47/001.96/02276/019
1131:38 SSR 081.80/001.59/02076/017
1131:45 SSR 099.69/000.84/01479/011

1131:49 P100 R81 OPTICAL TRACK 066.19/001.68/01315
1131:53 SSR 166.52/000.48/01177/008

1131:53 P100 R81 LAUNCH 066.73/001.22/00987 SSS LAUNCHED
1132:01 SSR 217.59/001.21/01079/007
1132:09 SSR 220.87/002.14/01079/007
1132:16 SSR 209.78/002.86/01177/008

1132:22 SSR 205.15/003.67/01279/009
 1132:30 SSR 198.43/004.46/01778/014
 1132:32 P100 R81 DISENGAGE
 1132:37 SSR 194.27/005.32/01876/015
 1132:38 RC END RUN 4
 1132:40 RC START RUN 5
 1132:45 SSR 191.65/006.20/01876/015
 1132:52 SSR 187.71/007.02/01978/016
 1133:00 SSR 186.56/007.93/02076/017
 1133:07 SSR 185.57/008.84/02076/017
 1133:14 SSR 184.78/009.75/02477/021
 1133:21 SSR 181.28/010.30/02076/017
 1133:27 R208 BH5 ENGAGE
 1133:29 SSR 178.00/010.46/01479/011
 1133:33 SSR 175.88/010.45/01377/010
 1133:43 SSR 168.98/009.62/01177/008
 1133:50 SSR 167.42/008.77/00879/005
 1133:55 SSR 169.91/008.12/00879/005
 1134:05 SSR 168.83/006.92/00777/004
 1134:07 R223 R8 ENGAGE
 1134:12 SSR 167.32/005.98/00777/004
 1134:19 SSR 164.95/005.05/00777/004
 1134:26 SSR 162.53/004.08/00777/004
 1134:33 SSR 158.45/003.16/00777/004
 1134:40 SSR 147.53/002.62/00000/000
 1134:47 SSR 137.41/002.75/01978/016
 1134:51 SSR 131.97/003.08/01377/010
 1134:52 P208 BC ENGAGE
 1134:54 SSR 128.76/003.42/01079/007
 1134:55 R208-1 BH5 ACQUIRED 131.09/001.16/00961
 1135:02 SSR 123.86/004.23/00879/005
 1135:06 R208 BH5 ECM 112.27/001.16/00980
 1135:07 R208 BH5 SCORE D
 1135:09 SSR 125.25/005.04/00977/006
 1135:16 SSR 123.17/005.83/00879/005
 1135:18 P208 BC NOT FOUND
 1135:19 R208 BH5 DISENGAGE
 1135:19 R223 R8 DISENGAGE
 1135:19 P208 BC DISENGAGE
 1135:24 SSR 120.11/006.62/00977/006
 1135:26 RC END RUN 5
 1135:31 SSR 121.50/007.38/01578/012
 1135:35 RC START RUN 6
 1135:38 SSR 124.03/008.06/01978/016
 1135:46 SSR 126.30/008.77/02276/019
 1135:53 SSR 126.83/009.53/02378/020
 1136:00 SSR 125.78/010.30/02477/021
 1136:07 SSR 125.18/011.09/02677/023
 1136:15 SSR 126.54/011.83/02778/024
 1136:27 R208 BH5 ENGAGE
 1136:37 SSR 132.53/010.88/01679/013
 1136:42 SSR 132.88/010.32/01479/011
 1136:46 SSR 132.09/009.94/01479/011
 1136:49 SSR 131.64/009.52/01377/010
 1136:50 P208 BC ENGAGE
 1136:53 P223-2 BC optical tracking 182.63/002.00/01341
 1136:53 P223 BC LOST CONTACT 182.63/002.00/01341
 1136:54 P223 BC TERRAIN MASKING
 1136:57 SSR 130.32/008.66/01177/008
 1137:04 SSR 128.65/007.79/01177/008
 1137:06 SSR 126.14/007.68/01177/008
 1137:13 SSR 124.33/006.77/01177/008
 1137:19 SSR 124.83/005.88/01279/009
 1137:27 SSR 121.39/004.96/01079/007
 1137:34 SSR 116.68/004.03/00977/006
 1137:41 SSR 108.84/003.21/00977/006
 1137:47 P208 BL ENGAGE
 1137:49 SSR 093.30/002.55/01578/012
 1137:52 R208 BH5 ECM 103.67/001.30/00994
 1137:52 P208-2 BL optical tracking 182.59/004.93/00000
 1137:52 P208 BL BREAKLOCK 182.59/004.82/00000
 1137:53 R208 BH5 SCORE G
 1138:00 SSR 077.52/003.02/02378/020
 1138:03 SSR 073.19/003.38/01876/015
 1138:06 R208 BH5 ECM 083.82/000.11/01033
 1138:07 R208 BH5 SCORE G
 1138:10 SSR 067.76/004.07/01377/010
 1138:17 SSR 068.90/004.80/01279/009
 1138:17 P208 BL ACQUIRED 145.55/003.49/00052
 1138:19 P208-2 BL AUTO-TRACK 142.34/003.85/00000
 1138:25 SSR 072.72/005.53/00977/006
 1138:32 SSR 073.96/006.31/00879/005
 1138:39 SSR 076.97/007.06/00977/006
 1138:47 SSR 076.94/007.88/00879/005
 1138:52 SSR 078.43/008.33/00879/005
 1138:59 SSR 077.61/009.25/00879/005
 1138:59 R208 BH5 DISENGAGE

1138:59 P223 BC DISENGAGE
 1138:59 P208 BL DISENGAGE
 1139:01 SSR 075.92/009.51/00977/006
 1139:05 RC END RUN 6
 1139:08 SSR 077.29/010.23/02276/019
 1139:14 SSR 079.18/010.67/03077/027
 1139:14 RC START RUN 7
 1139:21 SSR 078.67/011.39/03379/030
 1139:29 SSR 077.97/012.19/03579/032
 1139:36 SSR 077.55/012.92/03779/034
 1139:43 SSR 076.94/013.75/03877/035
 1139:51 SSR 077.29/014.51/03979/036
 1139:58 SSR 078.14/015.21/04179/038
 1140:06 SSR 078.25/015.88/04376/040
 1140:13 SSR 076.51/016.40/04478/041
 1140:20 SSR 073.80/016.48/04278/039
 1140:28 SSR 071.48/016.08/03677/033
 1140:33 R208 BH5 ENGAGE
 1140:35 SSR 070.85/015.28/02677/023
 1140:43 SSR 071.24/014.42/01679/013
 1140:46 SSR 071.19/013.99/01279/009
 1140:57 SSR 069.31/012.79/00977/006
 1140:58 P208 BC ENGAGE
 1141:04 SSR 069.24/011.85/00879/005
 1141:06 P208 BL ENGAGE
 1141:12 SSR 069.35/010.91/00879/005
 1141:18 P223-1 BL ACQUIRED 101.19/007.56/00000
 1141:19 SSR 070.17/010.02/00977/006
 1141:20 P223-2 BL AUTO-TRACK 103.25/007.34/00000
 1141:26 SSR 074.64/009.70/00977/006
 1141:35 SSR 080.80/010.27/00879/005
 1141:40 P223 BL breaklock 112.98/009.02/00000
 1141:41 SSR 079.75/011.06/00679/003
 1141:44 P223 BL VISIBILITY 112.98/009.21/00000
 1141:48 SSR 081.82/011.81/00977/006
 1141:56 SSR 083.15/012.56/01978/016
 1142:01 P223 BC NOT FOUND
 1142:01 R208 BH5 NOT FOUND
 1142:02 R208 BH5 DISENGAGE
 1142:02 P223 BC DISENGAGE
 1142:02 P223 BL DISENGAGE
 1142:03 SSR 083.80/013.26/02677/023
 1142:05 RC END RUN 7
 1142:08 SSR 086.31/013.68/02979/026
 1142:08 RC START RUN 8
 1142:15 SSR 086.47/014.36/03379/030
 1142:23 SSR 086.21/015.03/03677/033
 1142:30 SSR 084.77/015.52/03877/035
 1142:37 SSR 082.25/015.75/03979/036
 1142:45 SSR 079.63/015.56/03979/036
 1142:52 SSR 077.70/015.04/03677/033
 1143:00 SSR 077.01/014.21/02877/025
 1143:07 SSR 076.56/013.41/01876/015
 1143:08 R208 BH5 ENGAGE
 1143:15 SSR 076.73/012.42/01279/009
 1143:22 SSR 077.31/011.46/00879/005
 1143:29 SSR 078.14/010.56/00679/003
 1143:37 SSR 078.20/009.62/00777/004
 1143:44 SSR 075.69/008.87/00777/004
 1143:52 SSR 075.34/007.95/00879/005
 1143:59 SSR 074.52/007.02/00879/005
 1144:06 SSR 074.07/006.08/00879/005
 1144:13 SSR 073.38/005.13/00879/005
 1144:21 SSR 072.19/004.17/00879/005
 1144:25 R208-1 BH5 ACQUIRED
 1144:26 R208-2 BH5 OPTICAL TRACK 076.28/000.67/01020
 1144:28 SSR 069.98/003.21/00977/006
 1144:29 R208-3 BH5 LAUNCH 076.40/001.47/01131
 1144:35 SSR 063.66/002.29/01079/007
 1144:37 R208 BH5 ECM 068.09/000.31/01000
 1144:42 SSR 042.07/002.21/01279/009
 1144:47 R208 BH5 SCORE D
 1144:57 SSR 037.72/003.80/01279/009
 1145:04 SSR 034.60/004.63/01279/009
 1145:08 R208 BH5 ECM 040.18/002.48/01456
 1145:12 R208 BH5 SCORE A
 1145:18 SSR 033.86/006.27/01279/009
 1145:22 R208 BH5 LOST CONTACT 036.87/005.51/02024
 1145:23 R208 BH5 TERRAIN MASKING 036.87/005.51/02024
 1145:33 R208 BH5 DISENGAGE
 1145:36 RC END RUN 8
 1145:39 RC START RUN 9
 1145:40 SSR 024.79/008.64/01377/010
 1145:47 SSR 022.38/009.37/01978/016
 1145:54 SSR 021.20/009.85/02477/021
 1145:58 SSR 019.81/010.19/02677/023
 1146:01 SSR 018.49/010.50/02778/024

PMR6

MOD/0/29A

1146:05 SSR 017.25/010.81/02877/025
 1146:09 SSR 016.09/011.10/02979/026
 1146:12 SSR 015.03/011.43/03179/028
 1146:16 SSR 013.94/011.76/03277/029
 1146:20 SSR 012.72/012.05/03379/030
 1146:23 SSR 011.40/012.32/03477/031
 1146:27 SSR 009.98/012.53/03579/032
 1146:31 SSR 008.35/012.69/03579/032
 1146:34 SSR 006.74/012.76/03579/032
 1146:38 SSR 005.04/012.79/03677/033
 1146:42 SSR 003.34/012.79/03877/035
 1146:45 SSR 001.68/012.81/04179/038
 1146:49 SSR 000.03/012.84/04576/042
 1146:53 SSR 358.47/012.86/04878/045
 1146:57 SSR 356.99/012.89/05278/049
 1147:06 SSR 351.63/013.14/05977/056
 1147:13 SSR 349.70/013.21/06079/057
 1147:17 SSR 348.29/013.29/06079/057
 1147:21 SSR 346.96/013.38/06079/057
 1147:24 SSR 345.61/013.48/06079/057
 1147:28 SSR 344.18/013.59/06079/057
 1147:32 SSR 342.89/013.69/06079/057
 1147:35 SSR 341.59/013.81/06079/057
 1147:39 SSR 340.33/013.95/06079/057
 1147:43 SSR 339.06/014.06/06079/057
 1147:46 SSR 337.84/014.20/06177/058
 1147:50 SSR 336.64/014.34/06177/058
 1147:54 SSR 335.47/014.49/06177/058
 1147:58 SSR 334.30/014.63/06177/058
 1148:01 SSR 333.18/014.79/06177/058
 1148:05 SSR 332.07/014.95/06177/058
 1148:09 SSR 330.94/015.13/06177/058
 1148:12 SSR 329.86/015.29/06177/058
 1148:16 SSR 328.86/015.48/06177/058
 1148:20 SSR 327.76/015.65/06177/058
 1148:23 SSR 326.79/015.84/06177/058
 1148:27 SSR 325.79/016.02/06177/058
 1148:31 SSR 324.96/016.25/06177/058
 1148:35 SSR 324.29/016.54/06177/058
 1148:38 SSR 323.74/016.81/06177/058
 1148:42 SSR 323.44/017.16/06177/058
 1148:46 SSR 323.13/017.45/06177/058
 1148:49 SSR 323.13/017.79/06177/058
 1148:53 SSR 323.44/018.13/06177/058
 1148:57 SSR 323.75/018.41/06177/058
 1148:58 R208 BH5 ENGAGE
 1149:01 SSR 324.49/018.69/05977/056
 1149:04 SSR 325.34/018.90/05777/054
 1149:08 SSR 326.53/019.07/05377/050
 1149:12 SSR 327.58/019.05/04977/046
 1149:16 SSR 328.70/018.93/04678/043
 1149:19 SSR 329.83/018.75/04278/039
 1149:23 SSR 330.50/018.39/03979/036
 1149:27 SSR 331.46/018.08/03579/032
 1149:30 SSR 332.10/017.70/03179/028
 1149:34 SSR 332.54/017.24/02578/022
 1149:38 SSR 332.99/016.80/02076/017
 1149:41 SSR 333.51/016.35/01778/014
 1149:45 SSR 333.95/015.90/01679/013
 1149:49 SSR 334.50/015.45/01479/011
 1149:52 SSR 334.99/015.00/01377/010
 1149:56 SSR 335.39/014.52/01279/009
 1150:00 SSR 335.77/014.09/01177/008
 1150:03 SSR 336.16/013.61/01079/007
 1150:07 SSR 336.86/013.15/01079/007
 1150:11 SSR 338.04/012.76/01079/007
 1150:14 SSR 339.34/012.33/01079/007
 1150:22 SSR 341.20/011.51/01679/013
 1150:25 SSR 341.34/011.04/01679/013
 1150:29 SSR 341.25/010.58/01578/012
 1150:32 SSR 341.36/010.04/01479/011
 1150:36 SSR 341.33/009.56/01479/011
 1150:40 P208 BL ENGAGE
 1150:40 SSR 341.54/009.07/01479/011
 1150:43 SSR 340.96/008.63/01578/012
 1150:47 SSR 341.63/008.07/01578/012
 1150:51 SSR 341.94/007.57/01479/011
 1150:54 SSR 342.50/007.06/01479/011
 1150:58 SSR 341.67/006.63/01479/011
 1151:02 SSR 341.38/006.14/01578/012
 1151:05 SSR 341.51/005.81/01679/013
 1151:13 SSR 341.35/004.85/01578/012
 1151:17 P223-1 BL ACQUIRED 256.09/003.77/01118
 1151:18 P223-2 BL AUTO-TRACK 255.39/003.75/01118
 1151:19 R208-1 BH5 ACQUIRED
 1151:20 R208-2 BH5 OPTICAL TRACK 339.74/010.65/05206
 1151:22 P100 R81 ENGAGE

1151:24 SSR 330.65/003.58/01679/013
1151:31 P223 BL breaklock 247.79/004.78/00000
1151:32 P223 BL TERRAIN MASKING 247.78/004.86/00000
1151:33 R208-3 BH5 LAUNCH 315.66/010.65/04832 OUTSIDE MAX MISSILE RANGE
1151:34 SSR 312.46/003.92/01479/011
1151:41 SSR 299.75/003.89/01479/011
1151:57 SSR 291.62/002.10/01279/009
1152:02 P223-1 BL ACQUIRED 221.24/005.87/00000
1152:03 P223-2 BL AUTO-TRACK 221.24/005.86/00000
1152:05 SSR 293.78/001.23/01177/008
1152:14 R208 BH5 LOST CONTACT 297.49/010.53/11702
1152:19 P100 R81 OPTICAL TRACK 053.45/001.55/01007
1152:20 P100 R81 LAUNCH 056.89/001.62/00994 SSS LAUNCHED
1152:20 SSR 099.35/000.78/01079/007
1152:28 SSR 116.16/001.63/01177/008
1152:28 R208 BH5 ELEVATION 116.28/010.59/08418
1152:43 SSR 160.18/002.40/00977/006
1152:50 SSR 172.95/003.09/00879/005
1152:51 P100 R81 LAUNCH 145.21/002.51/00885 SSS LAUNCHED
1152:58 SSR 177.24/003.91/01978/016
1153:00 R208 BH5 DISENGAGE
1153:00 P100 R81 DISENGAGE
1153:00 P223 BL DISENGAGE
1153:04 SSR 181.15/004.58/04278/039
1153:05 RC END RUN 9
1153:11 SSR 178.92/005.19/05977/056
1153:20 SSR 174.03/005.78/06679/063
1153:26 SSR 173.94/006.42/07178/068

PMR6

MOD/0/29A

END MISSION 1132
TS BH1 T1 5502590N 00233250W 00945 20 A202
TS BH5 SA8 5503073N 00233109W 00932 10 R208
TS PL SA6 5502255N 00238071W 00951 40 R206
TS R8 ZSU 5502053N 00234426W 00787 20 R223
TS R81 IR 5502069N 00234435W 00801 10 P100
TS BC JETS5503007N 00221261W 01417 10 P208
TS BL JETS5507552N 00229094W 01460 20 P208



